


FIG.9



VL1500Y E03 E28_009
DECAMP SHAFT

REF#	PART	#REQ	REMARKS
1	SHAFT, DECOMP FRONT 12939-38B00	1	
2	LEVER, DECOMP FRONT 12942-10F00	1	
3	NUT, IDLE GEAR SHAFT	2	

	08316-1008A	
4	SEAL, CL RLSE ARM 09282-10012	2
5	HOLDER, DECOMP CABLE FRONT 12944-10F00	1
6	SCREW (GREEN) 02122-05103	4
7	SPRING, DECOMP SHAFT FRONT 09448-17031	1
8	SHAFT, DECOMP REAR 12941-38B00	1
9	LEVER, DECOMP REAR 12952-10F00	1
10	HOLDER, DECOMP CABLE REAR 12950-10F00	1
11	SPRING, DECOMP SHAFT REAR 09448-17020	1
12-1	BOLT 01550-0630A	1
12-2	BOLT (GREEN) 02162-06303	1
13-1	BOLT 01550-0625A	1
13-2	BOLT 02162-0625A	1
14	WASHER, OIL GALLERY EXHAUST 09168-06023	2
15	CABLE, DECOMP FRONT 58900-10F00	1
16	CABLE, DECOMP REAR 58910-10F10	1

(close window)