

This exploded view diagram illustrates the assembly of a vehicle wheel and suspension system. The components are numbered as follows:

- Wheel Assembly (Top):**
 - 1: Wheel rim
 - 2: Wheel hub
 - 3: Wheel axle
 - 4: Wheel nut
 - 5: Wheel washer
 - 6: Wheel flange
 - 7: Wheel bolt
 - 12: Wheel nut
 - 14: Wheel washer
 - 15: Wheel washer
 - 16: Wheel nut
 - 22: Wheel tire
 - 23: Wheel bolt
 - 24: Wheel nut
- Suspension Assembly (Bottom):**
 - 1: Suspension arm
 - 2: Suspension nut
 - 3: Suspension arm
 - 4: Suspension nut
 - 5: Suspension washer
 - 6: Suspension nut
 - 7: Suspension washer
 - 8: Suspension arm
 - 9: Suspension nut
 - 10: Suspension washer
 - 11: Suspension arm
 - 12: Suspension nut
 - 13: Suspension arm
 - 14: Suspension nut
 - 15: Suspension washer
 - 16: Suspension nut
 - 17: Suspension arm
 - 18: Suspension nut
 - 19: Suspension washer
 - 20: Suspension nut
 - 21: Suspension washer

A 'FWD' arrow points to the left, indicating the front of the vehicle.

VL1500Y E03 E28_056
REAR WHEEL

REF#	PART	#REQ	REMARKS
1	WHEEL SET, REAR (MT5.00X15) 64100-10810-12R	1	
2	.BUSH, REAR HUB 09319-12019	6	
3	SPACER, REAR HUB BEARING	1	

	09180-20112	
4	BEARING, RH 08133-62047	1
5	BEARING, REAR HUB, LH 09262-20042	2
6	DISC, REAR BRAKE 69210-10F00	1
7	BOLT (8X33) 09106-08148	6
8	BRACKET, REAR CALIPER 69721-10F01	1
9	PIN, BRACKET 64241-10F00	1
10	NUT 08319-31123	1
11	AXLE, REAR 64711-10F00	1
12	SPACER, AXLE RH 64740-10F00	1
13	SPACER, AXLE LH 64772-10F00	1
14	WASHER 08322-01183	1
15	NUT 09159-18004	1
16	CAP, LH 64792-38B00	2
17	JOINT, HUB DRIVEN 64680-24A00	1
18	O RING, DRIVEN JOINT 09280-65003	1
19	WASHER, THRUST 64677-45110	3
20	BOLT, DRIVEN JOINT WASHER 09119-06049	6
21	WASHER, JOINT 09169-06030	3
22	TIRE, REAR (180/70-15M/C 76H) 65110-10F00	1
23	VALVE ASSY, WHEEL RIM (TR412) 43130-24A00	1
24-1	BALANCER, WHEEL (10G) 43222-73H10	0%3
24-2	BALANCER, WHEEL (20G) 43224-73H10	0%3
24-3	BALANCER, WHEEL (30G) 43226-73H10	0%3